

## How to separate the Triple Slide Runner (Roller and Rail)

The Triple Slide Rail system comes in a variety of sizes and colour as shown, but not limited to samples shown below. The part numbers will also come in a variety of codes, mainly Z2 & X2 or Y2 & W2.



**This following example is for Y2 and X2 pieces, but is applicable to all Triple Slide Rollers & Rail.**

1. Pieces Y2 and X2 are inter-connected together, on one side is Z2




2. When flipped upside-down, you can see Y2



3. In order to separate the two pieces, extend as shown below




4. Until it is fully extended as shown below with Z2 label facing up (circled in blue)








5. Now locate the lever which is shown in the picture above and below (circled in red)



6. Flip the flip the lever as shown in the following pictures




7. Now holding flipped lever with one hand, hold the larger piece with your other hand and pull them apart as shown in the following diagrams.





8. The end piece with the lever should slide out and become a separate piece as shown below.



9. If you flip over the end piece over as shown below, you will see that it is the Y2 piece

